

TANK INSTALLATION FROM NIPLAST®

Delivery & Installation Methods To Suit All Requirements

- **EX. WORKS**
- **DELIVER & CLIENT TO UNLOAD**
- **DELIVER & OFFLOAD**
- **DELIVER, OFFLOAD, POSITION & BOLT-DOWN**

Depending on the end user's needs and the intricacy of the tank system, NIPLAST® can provide a range of installation techniques.

EX. WORKS SUPPLY:

Upon manufacturing completion, the client will collect the tank or tanks from NIPLAST®, using their own transportation, the tank will be loaded by NIPLAST®. Off-loading advice will be available from NIPLAST®.

DELIVER & CLIENT TO UNLOAD:

The tank is delivered by Niplast's transportation system. The client is responsible for off-loading of the tank(s) from the delivery vehicles, installation and setup thereafter.

DELIVER & OFFLOAD:

NIPLAST® undertake delivery of the tank(s) to site and their subsequent off-loading to adjacent plinths, typically using hi-abs and/or cranes. Bolting tanks down and other installation measures are excluded.

DELIVER, OFFLOAD, POSITION & BOLT-DOWN:

Our most comprehensive shipping and tank installation service. In addition to the above option, we will position and bolt-down the tank to the plinth utilising the requisite bolting process and resin application. If requested tank steelwork such as ladders and hand-railing can be fitted at this time.



To request a quote or discuss further with an expert email info@niplast.com or call **0161 477 6777**

niplast
STORAGE TANKS